# **Tenda**


## **Quick Installation Guide**

Outdoor CPE O1/O1-5G/O3/O4/O6/OS3

### Package contents

Item	01	O1-5G	03	04	06	OS3
CPE	1					
PoE injector	1	1	1	1	1	1
Power adapter	1	1	1	1	×	1
Power cord	×	×	×	×	1	×
Plastic strap	2	1	2	2	2	2
Ethernet cable	×	×	1	×	×	×
Screw for fixing the PoE injector	2	2	2	2	×	2
Expansion bolt	2	2	2	2	×	2
Grounding screw	×	×	1	×	1	×
Quick insta <b>ll</b> ation guide	√					

### Get to know the PoE injector



Port	Description
DC, ①	Powerjack
PoE	PoE power output port. Use an Ethernet cable to connect this port to the passive PoE port of the CPE.
LAN	LAN port Used to connect to an upstream network device, computer, switch, camera, or other device.

Get to know your device The CPE appearance varies with models. Please refer to the CPE you purchased.

#### **LED indicators/slots**


LED indicator/Slot Status Description

The following table lists all LED indicators that may be used on the CPE. However, the LED indicators and slots may vary with CPE models.

Power	Solid on	CPE powered on		
Power	Off	CPE powered off		
	Solid on	CPE powered on without data transmission		
LAN/WAN, PoE/LAN	Blinking	CPE powered on with data transmitting		
	Off	CPE powered off		
	Solid on	Corresponding port connected without data transmission		
PoE/LAN1, LAN2, LAN3, LAN4	Blinking	Corresponding port connected with data transmitting		
	Off	Corresponding port disconnected		
WiFi	Solid on	WiFi enabled without data transmission		
	Blinking	WiFi enabled with data transmitting		
	Off	WIFi disabled		
LED1, LED2, LED3 (Received signal strength indicator)	Solid on/ blinking	CPE bridged or connected to other devices - Solid on: CPE working in AP, Repeater, P2MP or Router mode - Blinking: CPE working in Client, Universal repeater or WISP m The more indicators are on, the better the connection quality is \( \docs \), Tips You can change the signal strength values for each indicator on the Wireless > Advanced page in the web UI of the CPE.		
	Off	No device connected to the CPE wirelessly, or weak signal strengt Adjust your CPE's direction or location.		
Wall mounting slots		Prepare 4 expansion bolts and 4 screws for wall mounting.  Recommended specifications:  - Expansion bolt: outer diameter: 6 mm; length: 40 mm  - Screw: thread diameter 3 mm; length: 20 mm;  5.5 mm < head diameter < 8.5 mm		
Pole mounting slots		You can thread the included plastic straps through these slots to		

### Ports/button

For some models, you need to remove the cover to see the ports and buttons. OS3 is used for example in the following figure.




The following table lists all ports and buttons that may be used on the CPE. However, the  $\,$ 

Port/Button	Description  DC power jack. Connect the power adapter (if any) to this port for power supply.		
12V 1A, DC			
PoE LAN/WAN, PoE/LAN, PoE/LAN1, LAN1 12V PoE, LAN2 802.3af PoE	Multiplexing port for power input and data transmission.  - If passive PoE is used for power supply, connect this port to the PoE port of the PoE injector.  - If you power on the CPE using a power adapter, this port can be connected to a computer, switch or IP camera.  - If standard PoE is used for power supply, connect this port to the PoE port of the IEEE 802.3af/at PoE power supply device. You can check whether the CPE supports standard PoE power supply on the package box or the CPE's Specifications page on www.tendacn.com.  - \( \dots\). Tips  - If the CPE works in the Router mode (if supported), this port functions as a WAN port to connect to an upstream network device.  - LAN12V PoEpor to only supports passive PoE. LAN2 802.3af PoE port only supports standard PoE.		
LAN,LAN2,LAN3,LAN4	Ethernet port for connecting to a computer, switch or IP camera.		
RST, RESET, Reset	Reset button. Used to restore the CPE to factory settings. For details, see <b>Q2</b> in <b>FAQ</b> .		
Cable grommet	Used to fix the power cord or Ethernet cable.		
GND	Grounding terminal.  Use a grounding cord and included grounding screw to connect the grounding terminal to the earth or building for surge and lightning protection.		
Power cord/grounding cord/ Ethernet cable inlet	Used to fix the power cord of the power adapter, grounding cord, or Ethernet cable.		

#### Power on the CPE


#### Option 1: Use the PoE injector



#### Option 2: Use the power adapter

If your CPE has a DC power jack, use the included power adapter to power on the CPE.





### Scenario 1: CCTV surveillance or point to point data transmission




#### **Option 1: Automatic bridging (recommended)** Peer-to-peer bridging

 $Place \,two\,CPEs\,in\,factory\,settings\,next\,to\,each\,other,\,open\,their$ covers and power them on. After the CPEs complete startup, they start automatic bridging and

their LED1, LED2 and LED3 indicators blink quickly. About 1 minute

later, when the LED1, LED2 and LED3 indicators of one CPE light solid

on and those of the other CPE blinks slowly, the automatic bridging After the bridging succeeds, the DHCP server of the CPEs will be disabled automatically. The IP address of the CPE working in AP mode remains 192.168.2.1, and the IP address of the CPE working in Client mode is changed into 192.168.2.2.




If the automatic bridging fails, restore the two CPEs to factory settings by referring to Q2 in FAQ

Peer-to-multiple peers bridging For peer-to-multiple peers bridging, perform peer-to-peer bridging first, and then power on the rest CPEs within 30 minutes. Otherwise, the bridging may fall.
 One CPE can bridge with 15 CPEs at most.

Step1: Choose any two CPEs, then perform Peer-to-peer bridging. **Step 2:** Within **30 minutes** after peer-to-peer bridging succeeds, put other CPEs in factory settings near the CPE working in AP

mode (LED1, LED2 and LED3 are solid on), and power them on. After the other CPEs complete startup, they start automatic bridging and their LED1, LED2 and LED3 indicators blink quickly. About 1 minute later, when their LED1, LED2, and LED3 indicators blink slowly, the bridging succeeds.

After the bridging succeeds, the DHCP servers of the CPEs are disabled, and the IP addresses of CPEs working in Client mode are all changed into 192.168.2.2. You can visit www.tendacn.com to download the CPE management software and install it on your computer to change the CPEs' IP addresses in batches




## **Option 2: Manual bridging**

Step1: Place two CPEs next to each other

Step2: Log in to the web UI of CPE1. ① Open the CPE1 cover and power it on (PoE injector used in this

2 Connect client to CPE1. Method 1: Connect your wireless client (such as a smartphone) to the WiFi network of CPE1. By default, the WiFi name of CPE1 is **Tenda\_XXXXXX** (**XXXXXX** indicates the last six characters of the MAC address). If a WiFi QR code is provided on the CPE1 nameplate, you can scan it to connect to the WiFi network directly.

Method 2: Use an Ethernet cable to connect the LAN port of the PoE injector to a computer. The PoE/LAN1 indicator of CPE1



3 Start a web browser on the client connected to CPE1 and visit 192.168.2.1. Enter the login username and password and click



Step3: Set CPE1 to AP mode. • Access the Quick Setup page, select AP, and click Next. Q Customize your SSID (WiFiname) and Key (WiFi password)

and an Encryption Algorithm. Click Next.

Select a Channel, a Security Mode (WPA2-PSK recommended

Record the **SSID** and **Key** for later setup. Quick Setup >> AP

3 Click Save, and wait until CPE1 reboots automatically to activate

Step4: Set CPE2 to Client mode. 1 Perform Step 2 to log in to the web Ul of CPE2. 2 Access the Quick Setup page, select Client, and click Next. 3 Select the SSID of CPE1, which is Tenda\_123456 in this example,





**5** Set the IP address to an unused one belonging to the same network segment as that of CPE1. For example, if the IP address of CPE1 is 192.168.2.1, you can set CPE2's IP address to 192.168.2.X (X range



6 Click Save, and wait until the CPE reboots to activate the settings The LED1, LED2 and LED3 indicators of CPEs will blink quickly when they start bridging. When the LED1, LED2 and LED3 indicators of CPE1 light solid on, and the LED1, LED2 and LED3 indicators of CPE2 blink slowly, the bridging succeeds and the To perform peer-to-multiple bridging, log in to other CPEs and repeat Step 4 to set them to the Client mode and bridge them with the CPE working in AP mode.

### 2.Install the CPEs

The CPE is usually deployed in schools, communities, factories or streets for surveillance. Pole mounting is used for illustration here.


• Choose the elevated, open location for installation. 2 Thread the two plastic straps through the pole mounting slots on the bracket of the CPE, and attach the CPE onto the selected pole. Adjust the CPE's location and direction, and

tighten the straps to fix the CPE. Connect the CPEs with the LED1, LED2 and LED3 indicators solid on (AP mode - the

transmitting end) to the switch which is connected to a Network Video Recorder (NVR).

**⑤** Connect the CPEs with the LED1, LED2 and LED3 indicators blinking (Client mode − the receiving end) to IP cameras or a switch connected to IP cameras. **6** Install the CPE cover.

After successful installation, the connection quality reaches the best when the LED1, LED2 and LED3 indicators of the CPEs light solid on or blink.




## Scenario 2: Wireless ISP hotspot access

## 1.Set up the CPE

and try again.

Step1: Perform Step 2 in Option 2: Manual bridging under Scenario 1: CCTV surveillance or point to point data transmission to log in to the web UI of the CPE.



Select the SSID of the Internet Service Provider (ISP) hotspot, which is  $\textbf{Tenda\_123456}$  in this example, and click Next.



### 3 Enter the password for the ISP hotspot in the Key box, and click Next. Quick Setup >> WISP

Upstream AP Tenda 123456 Channel

4 Select the Internet Connection Type of your ISP hotspot. PPPoE is  $used \, for \, illustration \, here. \, Enter \, the \, PPPoE \, user \, name \, and \, password \,$ provided by your ISP, and click Next.



#### **6** Customize the **SSID (WiFi Name)**, select a **Security Mode** (WPA2-PSK recommended), customize a Key, and click Next.




**6** Set the IP address to an unused one belonging to a different network segment as that of the ISP hotspot. For example, if the IP address for the ISP hotspot is 192.168.2.1, you can set this CPE's IP address to 192.168.X.1 (X ranges from 0 to 254 excluding 2). Then click Next



## Click Save, and wait until the CPE reboots to activate the settings

 ${\sf CPE}\, is\, connected\, to\, the\, {\sf ISP}\, hot spot\, successfully.$ 



## 2. Install the CPE

Pole mounting is used for illustration here.

 Place the CPE over the roof. 2 Thread the two plastic straps through the pole mounting slots on the brackets of the CPE, and attach the CPE onto the selected pole. Adjust the CPE's location and direction, and tighten the  $\,$ straps to fix the CPE.

3 Power on the CPE. Ocnnect the LAN port of the CPE to the WAN port of your wireless The connection quality reaches the best when the LED1, LED2 and  $\,$ LED3 indicators of the CPE blink.




## Grounding

This part applies to the CPE with a GND terminal. O6 is used for example here.

3 Connect the other side of the grounding cord to the grounding terminal connected to the

Connect the GND terminal of the CPE to a grounding terminal connected to the earth or building, to protect the CPE from overvoltage and overcurrent caused by lightning.

• Connect one side of the grounding cord to the included grounding screw. ② Connect the grounding screw to the GND terminal of the CPE, and tighten it.



## **FAQ**

A1: Try the following solutions:

Q1: I cannot log into the web UI of the CPE by entering 192.168.2.1. What should I do?

• Ensure that the IP address of the computer is set to 192.168.2.X (X ranges from 2 - 254 and is unused).  $\bullet$  Restore the CPE to factory settings by referring to  ${\bf Q2},$  and try again.  ${\sf A2:}\,\textbf{Note:}\,\textbf{Resetting}\,\textbf{the CPE}\,\textbf{clears}\,\textbf{all}\,\textbf{settings,}\\ \textbf{and}\,\textbf{you}\,\textbf{need}\,\textbf{to}\,\textbf{configure}\,\textbf{it}\,\textbf{again.}$ 

Method 1: After the CPE completes startup, hold down the reset button (RST, RESET or Reset) for about 8 seconds and release it when all LED indicators light up. The CPE is restored to factory settings.

Input voltage Maximum PoE power supply distance

Q3: What is the maximum distance for PoE power supply when a PoE injector is used for power supply? A3: The following table is for your reference. You can check the power supply data on the CPE housing, power

Method 2: Log in to the web UI of the CPE, navigate to Tools > Maintenance, and click Reset.

12V 1A D	C power supply/PoE power supply	9-13V	50 m or 60 m
24V 0.5	PoE power supply	18-25V	60m
4: How to ch	eck that the CPE is under the be	st connection st	atus?
A4: <b>Method 1</b>	Observe the LED indicators of th LED1, LED2 and LED3 indicators		ection quality reaches the best when the t solid on or blink.
Method 2	Log in to the web UI of one CPE (o status in <b>Status</b> > <b>Wireless Sta</b>		s: 192.168.2.1), and check the bridging
	Stronger signal strength (-60 dF	3m hetter than =7	0 dBm), less background noise (-100 dBm

better than -90 dBm), and faster transmit/receive speed lead to better bridging signal. Example: OS3



9V 0.6A DC power supply/PoE power supply 9-13V

A5: Try the following solutions:

LED3 are solid on.

• Peer-to-peer bridging: If the peer-to-peer bridging fails, restore the two CPEs to factory settings by Peer-to-multiple peers bridging: After peer-to-peer bridging succeeds, ensure that the rest CPEs are - For the CPEs that fail to bridge within 30 minutes after peer-to-peer bridging succeeds, reset them and try


- Beyond 30 minutes after peer-to-peer bridging succeeds, refer to **Option 2: Manual bridging** to set the rest CPEs to Client mode, and then connect them to the WiFi network of the CPE whose LED1, LED2, and

Q6: After the bridging succeeds, the LED1, LED2 and LED3 indicators do not light up or only some of A6: Try the following solutions: • Ensure that the bridging distance between the CPEs is within the normal range.

Place the CPEs in an elevated location at the same height with few obstacles nearby.
 Make slight direction adjustment of the CPEs by moving it vertically and horizontally. Change the direction with an interval of 20s to 30s each time to observe the change of LED1, LED2 and LED3 indicators until the

Q7: After the installation succeeds, there is no display of the scenes monitored by IP cameras at the NVR

side. What should I do? Ensure that all devices are working normally and connected properly.
 Ensure that the computer, NVR and IP camera are in the same network segment, and the NVR configuration. and IP camera configuration are correct. • If the IP camera can be scanned but cannot be added at the NVR side, ensure that the **Transparent Bridge** 



## **Get support and services**



 $For technical \, specifications, user guides \, and \, more \, information, \, please \, visit \, the \, product$ page or service page on www.tendacn.com. Multiple languages are available You can see the product name and model on the product label.

## **Safety Precautions**

Before performing an operation, read the operation instructions and precautions to be taken, and follow them to prevent accidents. The warning and danger items in other documents do not cover all the safety precautions that must be followed. They are only supplementary information, and the installation and maintenance personnel need to understand the basic safety precautions to be taken. - The device is suitable for mounting at heights > 2 m. - Do not use the device in a place where wireless devices are not allowed.

- Please use the included power adapter/PoE injector (if provided).  $\textbf{-If you power on the CPE using a power adapter: the mainsplug is used as the disconnect device, and shall are provided by the contract of the contract of$ remain readily operable; the power socket shall be installed near the device and easily accessible. - CPE operating temperature: -30°C-60°C; Power adapter operating temperature: 0-40°C

- Keep the device away from water, fire, high electric field, high magnetic field, and inflammable and

explosive items. - If such phenomena as smoke, abnormal sound or smell appear when you use the device, immediately stop tits power supply, unplug all connected cables, and contact the after-sales service might cause safety hazards.

 $For \ \textbf{l} a test \ safety \ precautions, see \ \textbf{Safety and Regulatory Information} \ on \ \textbf{www.tendacn.com}$ 

## FC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment should be installed and operated with minimum distance 20cm between the device and your body.

authority to operate the equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. 01/04V3.0/06V3.0/0S3V2.0: 2412-2462 MHz;

O1-5G/O4/O6/OS3: 5150-5250 MHz, 5725-5850 MHz NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's



This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.



# $\epsilon$

Earth ===

**CE Mark Warning** This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the This equipment should be installed and operated with a minimum distance 20cm between the device and your body NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

**Declaration of Conformity** Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the device is in compliance with Directive The full text of the EU declaration of conformity is available at the following internet address: https://www.tendacn.com/download/list-9.html

Attention: In EU member states, EFTA countries, Northern Ireland and Great Britain, the operation in the frequency range 5150MHz = 5250MHz is only permitted indoors. The operation in the frequency range 5470 MHz = 5725 MHz is permitted both indoors and outdoors.



Floor 6-8, Tower E3, No.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052

support.uk@tenda.cn (United Kingdom)

support.us@tenda.cn (North America Support)

© 2023 Shenzhen Tenda Technology Co., Ltd. All rights reserved. Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product subject to change without notice.