


English

I. Set up the router



- ① Attach the antennas to the router.
- ② Insert a SIM card into the slot on the bottom panel of the router.

Mini SIM card ✓ Micro SIM card + adapter ✓ Nano SIM card + adapter ✓

Português (Brasil)

I. Configurar o roteador

- ① Conecte as antenas ao roteador.
 - ② Insira um cartão SIM na abertura no painel inferior do roteador.
- Cartão Mini SIM ✓ Cartão Micro SIM + adaptador ✓ Cartão Nano SIM + adaptador ✓
- ③ Use o adaptador de alimentação incluído para ligar o PWR do roteador a uma fonte de alimentação.
- ④ Pressione o botão ON/OFF (Ligar/Desligar) para ligar o roteador. O LED indicador acende uma luz.

Aguarde alguns instantes. O roteador será conectado com êxito à Internet quando o indicador LED acender.

Dicas:
Se o indicador não se acender, consulte a Q1 na FAQ para encontrar uma solução.

II. Acessar a internet


- Conecte seu dispositivo com fio, como um computador, à porta WAN/LAN ou LAN do roteador usando um cabo Ethernet.
 - Conecte seu dispositivo sem fio, como um smartphone à rede Wi-Fi do roteador usando o Wi-Fi Name (Nome Wi-Fi) e a Wi-Fi Key (Chave Wi-Fi) localizados no painel inferior do roteador.
- Para configurar melhor o roteador, como realizar a alteração do nome e da chave WiFi, efetue o login na interface do usuário da web do roteador acessando [tendawifi.com](#) por meio de um dispositivo conectado. Você também pode baixar o aplicativo Tenda WiFi em seu smartphone para gerenciar o roteador.

Dicas:
Se você não conseguir fazer login na interface do usuário pela web do roteador, consulte Q3 em FAQ (perguntas mais frequentes).

- ③ Use the included power adapter to connect the PWR jack of the router to a power source.
 - ④ Press the ON/OFF button down to turn on the router. The LED indicator lights up. Wait a few seconds. The router is connected to the internet when the LED indicator lights up.
- Tips:
If the LED indicator does not light up, refer to Q1 in FAQ.

II. Access the internet


- Connect your wired device, such as a computer, to the WAN/LAN or LAN port of the router using an Ethernet cable.
- Connect your wireless device, such as a smart phone, to the Wi-Fi network of the router using the Wi-Fi Name and Wi-Fi Key labeled on the bottom panel of the router.



To further configure the router, log in to the web UI of the router by visiting [tendawifi.com](#) on a connected device. You can also download the Tenda WiFi App on your smartphone to manage the router.


Tips:
If you cannot log in to the web UI of the router, refer to Q3 in FAQ.

LED indicators



LED indicator	Status	Description
	Power LED indicator Solid on	The router is powered on properly.
	Power LED indicator Off	The router is powered off or not powered on properly.
	Internet LED indicator Solid on	The router is connected to the internet.
	Internet LED indicator Off	No internet access is available.
	Wi-Fi LED indicator Solid on	The Wi-Fi network is enabled.
	Wi-Fi LED indicator Blinking	The router is ready for WPS negotiation.
	Wi-Fi LED indicator Off	The Wi-Fi network is disabled.
	LAN LED indicator Solid on	At least one device is connected to a LAN port of the router.
	LAN LED indicator Off	No device is connected to any LAN port of the router.
	Signal strength LED indicator 3 bars	Excellent signal.
	Signal strength LED indicator 2 bars	Good signal.
	Signal strength LED indicator 1 bar	Fair signal.
	Signal strength LED indicator Off	No signal.

Ports & Buttons



Port/Button	Description
ON/OFF	Power button. Used to turn on or off the router.
PWR	Power jack. Used to connect to a power source to supply power for the router.
RST/WPS	Used to reset the router, or start WPS negotiation of the router. • Reset: Hold down the button for about 8 seconds, and release it when all LED indicators light off and then light up. The router is reset.
WPS	Through the WPS negotiation, you can connect your wireless devices to the Wi-Fi network without entering the Wi-Fi password. Method: Press the button, and the Wi-Fi LED indicator blinks. Configure WPS-enabled wireless devices within 2 minutes to start WPS negotiation with the router.
WAN/LAN	It can serve as a WAN port or an IPTV port. By default, the router is under 3G/4G router mode and it serves as a LAN port. When the router is set to the wireless router mode, or the Fallower function is enabled, it serves as a WAN port.
LAN	It can serve as a LAN port or an IPTV port. When serving as a LAN port, it can be connected to a computer, switch or other LAN device. When the IPTV function is enabled under the wireless router mode, it serves as the IPTV port to connect to the set top box.
Antenna socket	Used to connect to the included antennas to enhance the 3G/4G signal.

FAQ

Q1: The LED indicator does not light up. What should I do?

- A1: Start a web browser, and access [tendawifi.com](#):
- If you are required to enter a PIN code to unlock the SIM card, contact your ISP for the PIN code.
 - If you are required to enter APN parameters manually, enter these parameters provided by your ISP.
 - If the LED indicator is still off after you finish the Quick Setup Wizard, your SIM card may run out of money.
- If the problem persists, contact your ISP for help.

Q2: I cannot access the internet after setting up the router. What should I do?

- A2: Ensure that the LED indicator lights solid on. If not, refer to Q1.
- If the problem persists, try the following methods:
- For wired devices, such as computers:
 - Ensure that your computer is connected to port WAN/LAN or LAN properly.
 - Ensure that your computer is set to obtain an IP address automatically and obtain DNS server address automatically.
 - For wireless devices, such as smart phones:
 - Ensure that your wireless device connects to the Wi-Fi network of the router.
 - Log in to the web UI and change the Wi-Fi name and Wi-Fi password on [Wi-Fi Settings > Wi-Fi Name & Password](#) page. Connect to the Wi-Fi network you set and try again.

Q3: I cannot access the web UI of the router by visiting [tendawifi.com](#). What should I do?

- A3: Try the following solutions.
- If you log in with a wireless device, such as a smartphone:
 - Ensure that your wireless device is connected to the Wi-Fi network of the router.
 - Disable the cellular network of your wireless device.
 - Clear the cache of your web browser or change another web browser and try again.

If you log in with a wired device, such as a computer:

- Ensure that the computer has connected to the router properly.
- Ensure that the IP address of your computer is 192.168.0.X (X ranges from 2 to 254). If not, unplug and replug one end of the Ethernet cable connecting the router and the computer, and try again.
- Clear the cache of your web browser or change another web browser and try again.

Q4: Why cannot I find the Wi-Fi signal of the router?

- A4: Connect your computer to port WAN/LAN or LAN of the router to log in to the web UI. Navigate to [Wi-Fi Settings > Wi-Fi Name & Password](#) and ensure that:
- Ensure that the Wi-Fi networks are enabled.
 - Ensure that the Hide function is disabled.

Q5: How to change the Wi-Fi name and password?

- A5: Try the following methods:
- Method 1: Log in to the web UI of the router on a connected device, visit [tendawifi.com](#) or 192.168.0.1 and navigate to [Wi-Fi Settings > Wi-Fi Name & Password](#) to change them.
- Method 2: After you download the Tenda WiFi App and manage the router, run the App and find [Toolbox > Wi-Fi Name & Password](#) to change them.

Q6: Can I access the internet through both the SIM card and WAN port?

- A6: When you insert a SIM card and connect the WAN/LAN port to the internet at the same time, you can configure the Fallower function on the [Internet Settings](#), so the router can provide internet access through another mode when the mode method fails.

For product or function details, please go to [www.tendacn.com](#) to download the user guide.

Tenda

Quick Installation Guide

AC1200 Dual-band Wi-Fi 4G LTE Router
4G07

Package contents

- 4G LTE Router x 1
- Power adapter x 1
- Detachable antenna x 2
- Ethernet cable x 1
- Quick installation guide x 1



Scan to download the Tenda WiFi App to manage the router

For product or function details, please go to [www.tendacn.com](#) to download the user guide.

Caution:

Manufacturer: SHENZHEN HEWEISHUN NETWORK TECHNOLOGY CO., LTD.
Adapter Model: BN073-A09009E, BN073-A09009B

Input: 100~240V AC 50/60Hz 0.4A
Output: 9V/1A
---: DC Voltage

Operating Environment
• Temperature: 0°C~40°C
• Humidity: (10 ~ 90)%RH, non-condensing

For EU/EFTA, this product can be used in the following countries:

BE	BG	CZ	DK	DE	EE	IE	EL	ES	FR	HR	IT	CY	LV
LT	LU	HU	MT	NL	AT	PL	PT	RO	SI	SK	FI	SE	UK

Technical Support
Shenzhen Tenda Technology Co., Ltd.
6-8 Floor, Tower E3, NO.1001, Zhongshanhuang Road, Nanshan District, Shenzhen, China, 518052

USA hotline: 1-800-570-5892
Toll Free: 7 x 24 hours

Canada hotline: 1-888-998-8966
Toll Free: Mon - Fri 9 am - 6 pm PST

Hong Kong hotline: 00852-81931998

Global hotline: +86 755-2765 7180 (China Time Zone)

Website: [www.tendacn.com](#)
E-mail: support@tenda.com.cn

Copyright © 2020 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

Tenda® is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd.

Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

Русский

I. Настройка маршрутизатора

- ① Подключите антенну к роутеру.
- ② Вставьте SIM-карту в разъем в нижней панели роутера.

Мини-SIM-карта ✓ Микро-SIM-карта + адаптер ✓ Нано-SIM-карта + адаптер ✓

③ Используйте входящий в комплект адаптер питания для подключения разъема PWR маршрутизатора к источнику питания.

④ Нажмите кнопку ON/OFF, чтобы отключить маршрутизатор. Загорается светодиодный индикатор .

Подождите несколько секунд. Маршрутизатор успешно подключен к интернету, если светодиодный индикатор горит.

Если индикатор не загорается, обратитесь к Q1 в разделе FAQ, чтобы решить эту проблему.

II. Доступ в Интернет

- Подключите свой компьютер или другое проводное устройство к WAN/LAN-порту или LAN-порту на роутере по кабелю Ethernet.

• Подключите свой смартфон или другое беспроводное устройство к Wi-Fi-порту, используя Wi-Fi Name (имя Wi-Fi) и Wi-Fi Key (пароль Wi-Fi), указанные на нижней панели роутера.

Чтобы изменить имя Wi-Fi, пароль Wi-Fi и прочие настройки, с помощью подключенного устройства выполните вход в систему веб-интерфейса через сайт [tendawifi.com](#). Вы также можете загрузить приложение Tenda WiFi на свой смартфон для управления маршрутизатором.

Если вы не можете выполнить вход в систему веб-интерфейса маршрутизатора, обратитесь к Q3 в FAQ (чаще задаваемых вопросах).

Français

I. Réglage le routeur

- ① Fixez les antennes au routeur.
- ② Insérez une carte SIM dans la fente du panneau inférieur du routeur.

Mini carte SIM ✓ Micro carte SIM + Adaptateur ✓ Carte Nano SIM + Adaptateur ✓

③ Utilisez l'adaptateur secteur fourni pour connecter la prise PWR du routeur à une source d'alimentation.

④ Appuyez sur le bouton ON/OFF pour allumer le routeur. Le voyant LED s'allume.

Patienter quelques secondes. Le routeur est connecté avec succès à internet lorsque l'indicateur LED clignote.

Si l'indicateur ne s'allume pas, se référer à la question Q1 de FAQ pour trouver une solution.

II. Acc