


## Getting to know your device



LED Indicator	<b>Blinking orange:</b> Initializing and starting
	<b>Solid orange:</b> Not connected to a 2.4 GHz WIFI network
	<b>Blinking blue:</b> Connecting to a 2.4 GHz WIFI network
	<b>Solid blue:</b> Connected to a 2.4 GHz WIFI network
Button	<b>Off:</b> Powered off, or turned off using the App or voice-activated devices
	Press it to power on/off the socket. Hold it down for about 5 seconds and release it when the LED indicator blinks orange. The Smart Plug is restored to factory settings successfully. Follow the quick installation guide to configure it again.

## Maximum power of the Smart Plug: 2300W

### Common appliances and their power:

Common appliances	Power
Coffee Maker	800 W
Desk Lamp	235 W
Tower Fan	50 W
Humidifier	260 W
Toaster	850 W
LCD	270 W

## Configuring the device

### Note:

- The Smart Wi-Fi Plug only supports 2.4 GHz WIFI network.
- The default SSID (WIFI name) of the Smart Plug is Tenda\_Smart Plug\_XXXX. XXXX indicates the last four characters of its MAC address which can be found on the device.

- Download the **Tenda Bell** App onto your mobile WIFI-enabled device, such as a smart phone, by searching for **Tenda Bell** in the App Store or Google Play, or by scanning the QR code. Then, install the App.
- Follow the instructions in the App to configure your Smart Plug.



## FAQ

### Q1: What devices can I control with the Smart Wi-Fi Plug?

**A1:** You can control desk lamps, coffee makers, humidifiers, tower fans, and any other small household appliance whose rated power does not exceed the maximum power of the Smart Plug.

### Q2: What should I do when the LED indicator of the Smart Wi-Fi Plug lights solid orange?

**A2:** Try the following solutions:

- Check whether the WIFI network of your wireless router is enabled. If not, enable it.
- Check whether the WIFI name or password of your wireless router is changed. If so, reset the Smart Plug, and connect it to your wireless router again with the new WIFI name or password.
- Reset the Smart Plug, and re-configure it using the **Tenda Bell** App.  
**Reset method:** Hold down the power button  for about 5 seconds and release it when the LED indicator blinks orange.

### Q3: How to control the Smart Plug with voice-activated devices, such as Amazon Alexa or Google Assistant?

**A3:** In your **Tenda Bell** App, tap the Smart Plug in the **Device** page, then  >  (for Amazon Alexa) or  (for Google Assistant) to get the help.

For more questions, please visit [www.tendacn.com/en/faq/default.html](http://www.tendacn.com/en/faq/default.html) to get online supports.



For passthrough devices, plug the power strips into the integrated electrical sockets of the devices, but devices of the same or another type not be stacked in normal use.



### RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Operating Temperature: 0°C - 40°C  
Operating Humidity: (10% - 90%) RH, non-condensing

### Contact Us

contact.au@tenda.cn  
support.au@tenda.cn  
Australia hotline: 1300 836 320  
Global hotline: +86 755-2765 7180 (China Time Zone)  
Website: <http://www.tendacn.com>  
E-mail: support@tenda.com.cn

Tenda Australia Pty Ltd.  
S404b, Level 4, 20 Macquarie Street, Parramatta NSW 2150

### Copyright

© 2019 Shenzhen Tenda Technology Co., Ltd. All rights reserved.  
**tenda** is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

# Tenda

## Quick Installation Guide

### Smart Wi-Fi Plug

SP3