


## 1. Get to know your device



Product appearance may differ from your actual product due to different regional power specifications and models. This guide takes SP15 as an example.

<b>Power LED indicator</b>	<b>Blinking orange:</b> Initializing and starting.
	<b>Solid orange:</b> Disconnected from a 2.4 GHz Wi-Fi network.
	<b>Blinking green:</b> Connecting to a 2.4 GHz Wi-Fi network.
	<b>Solid green:</b> Connected to a 2.4 GHz Wi-Fi network.
	<b>Off:</b> Powered off, or turned off using the App or voice-activated devices.
<b>Protected LED indicator</b>	When it is under surge protection, the Protected LED indicator lights green.
<b>Button</b>	<b>On/Off:</b> Press the button once.
	<b>Reset:</b> Hold down the button for about 5 seconds release it when the LED indicator blinks orange. The Smart Wi-Fi Power Strip is reset successfully. Follow this guide to configure it again.
<b>Smart outlet</b>	Used to plug in your device and control your device on your smartphone. Each outlet is independent. You can control it by the Tenda Beli App.
<b>Smart USB port</b>	Used to charge your tablet, smartphone or other devices. You can control it by the Tenda Beli App. Output: 5 V/2.4 A each, 5 V/2.4 A total.

### Maximum power of the Smart Wi-Fi Power Strip:

Standards	Model	SP15/SP18
AU		2400 W

## 2. Configure the device

### Tips:

- The Smart Wi-Fi Power Strip only supports 2.4 GHz Wi-Fi network.
- The default SSID (Wi-Fi name) of the Smart Wi-Fi Power Strip is **Tenda\_Power Strip\_XXXX.XXXX** indicates the last four characters of its MAC address which can be found on the device.

- Download the **Tenda Beli** App onto your mobile Wi-Fi-enabled device, such as a smartphone, by searching for **Tenda Beli** in the **App Store** or **Google Play**, or by scanning the **QR code**.
- Follow the instructions in the App to configure your Smart Wi-Fi Power Strip.



## FAQ

### Q1: What devices can I control with the Smart Wi-Fi Power Strip?

**A1:** You can control any household devices whose rated power does not exceed the maximum power of the Smart Wi-Fi Power Strip.

### Q2: What should I do when I failed to control the Smart Wi-Fi Power Strip After adding it on the Tenda Beli App?

**A2:** Try the following solutions:

- If the LED indicator of the Smart Wi-Fi Power Strip light solid green.
  - Check whether the router is connected to the internet successfully.

If the LED indicator of the Smart Wi-Fi Power Strip light solid orange.

- Check whether the Wi-Fi network of your wireless router is enabled. If not, enable it.
- Check whether the Wi-Fi name or password of your wireless router is changed. If so, reset the **Smart Wi-Fi Power Strip**, and re-configure it using the **Tenda Beli** App.

**Reset method:** Hold down the button for about 5 seconds and release it when the LED indicator blinks orange.

### Q3: How to control the Smart Wi-Fi Power Strip with voice-activated devices, such as Amazon Alexa or Google Assistant?

**A3:** In your **Tenda Beli** App, tap the Smart Wi-Fi Power Strip in the **Device** page, then choose > (for **Amazon Alexa**) or (for **Google Assistant**) to get the help.



For passthrough devices, plug the power strips into the integrated electrical sockets of the devices, but devices of the same or another type not be stacked in normal use.

This product support wall mounting, the specifications of the recommended wall mounting tools are as follows:

Screw: KA4 x 25 mm, Head diameter: 7.1 mm, Head thickness: 2.1 mm, Carbon steel: Hardened  
Plastic anchor: Length: 25 mm



### RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Operating Temperature: 0°C ~ 40°C (32°F ~ 104°F)  
Operating Humidity: (10% ~ 90%) RH, non-condensing

### Contact Us (Australia)

contact.au@tenda.cn  
support.au@tenda.cn  
Australia hotline: 1300 836 320  
Global hotline: +86 755-2765 7180 (China Time Zone)  
Website: <http://www.tendacn.com>  
E-mail: support@tenda.com.cn

Tenda Australia Pty Ltd.  
S404b, Level 4, 20 Macquarie Street. Parramatta NSW 2150

### Technical Support

Shenzhen Tenda Technology Co., Ltd.  
6-8 Floor, Tower E3, NO.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052

USA hotline: 1-800-570-5892  
Toll Free: 7x24 hours

Hong Kong hotline: 00852-81931998  
Global hotline: +86 755-2765 7180 (China Time Zone)

Canada hotline: 1-888-998-8966  
Toll Free: Mon - Fri 9 am - 6 pm PST

Website: [www.tendacn.com](http://www.tendacn.com)  
E-mail: support@tenda.com.cn

### Copyright

© 2020 Shenzhen Tenda Technology Co., Ltd. All rights reserved.  
**Tenda** is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.

# Tenda

## Quick Installation Guide

Smart Wi-Fi Power Strip  
SP15/SP18